



# ANKER TOWBARS LIMITED

THE ORIGINAL TOWBAR COMPANY

Appleby Hill

Austrey

Warwickshire

CV9 3ER

Tel: +44(0) 1827 830039

Fax: +44(0) 1827 830862

Email: sales@ankertowbars.co.uk

## FITTING INSTRUCTION

Before fitting please read notes  
on reverse.

6902 Mercedes Sprinter Van 1995 on  
300mm wheelbase without step  
3550/4025mm wheelbase with step

<u>IN THE BOX</u>			<u>IN THE FITTING KIT CONT</u>		
A	1	Crossmember	F	2	M16x50 Nuts, Bolts & Washers
B	2	Side Plates	G	6	M10x50 Nuts, Bolts & Washers
C	2	Side Brackets	H	4	M10x40 Nuts, Bolts & Washers
			I	4	M12x35 Nuts, Bolts & Washers
			J	8	M12x90 Nuts, Bolts & Washers
			K	4	M10x30 Sets & Spring Wash
D	2	Side Arms	L	4	M10x25 Washers
E	2	Special 2 Hole Spacers	M	8	M12x35 Washers

1. On 208D remove and discard towing eye.  
On 308D and 312D loosen bolts holding step.
2. Position and assemble as sketches. NB. The Step side brackets are between C and the chassis.
3. Finally using F fit ball and wiring kit (not supplied with this kit). Tighten all nuts and bolts.

This towbar must be used with a type approved ball conforming in A-50-1 dimension with adequate D & S values.

We hope that you have found this bar easy to fit and that you will enjoy towing with the strength of an Anker Towbar behind you.

